



M-Sight Pro User Manual

V1.7

Contents

Chapter I Introduction.....	1
1.1 M-Sight Pro Introduction.....	1
1.2 Key Features.....	1
Chapter II Installation.....	2
2.1 System Operating Environment.....	2
2.2 Installation Guide.....	2
Chapter III Operations and Settings.....	3
3.1 Login.....	3
3.2 Menu.....	3
3.3 Device Manager.....	5
3.3.1 Add Device.....	5
3.3.2 Edit Device.....	9
3.3.3 Speed Test.....	10
3.3.4 Delete Device.....	10
3.4 Live View.....	12
3.4.1 Start Live View.....	12
3.4.2 Stop Live View.....	14
3.4.3 Video Stream Control Panel.....	14
3.4.4 PTZ Control Panel.....	15
3.4.5 Fisheye Control Panel.....	16
3.4.6 Alarm Output Control Panel.....	17
3.4.7 Quick Playback.....	18
3.4.8 View Favorites.....	18
3.5 Playback.....	20
3.5.1 Start Playback.....	20
3.5.2 Split Playback.....	22
3.5.3 Transcoding.....	23
3.5.4 Fisheye Control Panel.....	24
3.5.5 Stop Playback.....	25
3.6 File Manager.....	25
3.6.1 File Preview.....	25
3.6.2 Batch Management of the Files.....	26
3.7 Alarm Message.....	28
3.8 General.....	31
3.8.1 New Message Inform.....	31
3.8.2 Password Protection.....	32
3.8.3 Video Performance.....	33
3.8.4 Remember Last Play.....	34
3.8.5 Alarm Push Interval.....	34
3.8.6 Image Ratio.....	35
3.8.7 Alarm Video Push.....	35
3.8.8 Mobile Network Reminder.....	37
3.8.9 Show Stream Information.....	37

3.8.10 Bandwidth Saving Mode.....	38
3.8.11 Help.....	38
3.8.12 About.....	38
3.9 About device.....	39
Chapter IV Service.....	40

Chapter I Introduction

1.1 M-Sight Pro Introduction

The M-Sight Pro App provides a powerful mobile surveillance tool that enhances security by providing administrators flexibility to monitor the live video from the network cameras and NVRs via wireless network. It's a video management system that works with the network cameras and NVRs to provide video monitoring. The interface is simple and intuitive, with easy access to most functions, such as viewing live video, playback the recorded videos.

This user manual describes how to use and manage the M-Sight Pro in your networking environment. Some knowledge of networking environments would be beneficial to the reader. If you have any technical problems, please contact us.

1.2 Key Features

- ✧ Support simultaneously managing network camera and Milesight NVR
- ✧ Support Fisheye client-side dewarping
- ✧ Support scanning QR code to get a remote view via P2P
- ✧ Support Quick Playback
- ✧ Support Transcoding to get better playback performance
- ✧ Support Split Playback
- ✧ Support Alarm Output control
- ✧ Support alarm video push notification
- ✧ Support customized stream parameters
- ✧ Support 1/4/9/16 screen layouts for up to 64 channels displaying
- ✧ Support 1/4 screen layouts for up to 4 channels playback
- ✧ Support to playback with SD card files and HDD files
- ✧ Support image capture/video recording functions
- ✧ Support File management
- ✧ Support H.265/H.264 video compression
- ✧ Support dual stream
- ✧ Support iOS and Android handheld device

Chapter II Installation

2.1 System Operating Environment

iOS: iOS 8.0 or above.

Android: Android 4.0 or above.

2.2 Installation Guide

iOS: Download the app from the App Store and install it directly.

Android: Download the app from the Google Play and install it directly.


Or you can download the app from our website: http://www.milesight.com/product/MS_APP.asp


For Android system, another link is also available for you:

http://www.milesight.com/support/download.asp#software_jump


Chapter III Operations and Settings

3.1 Login


Click the icon  to open M-Sight Pro, after agreeing the privacy policy of Milesight Technology Co.,Ltd, it will pop up the window:



After login, the Live View interface will show up:





iOS





Android

3.2 Menu







Click the button  or slide the title to right to pop the menu:



What's more, you can operate the APP if you turn the mobile device from vertical to horizontal orientation. Just click the button  or slide from left to right to pop up the menu.



You can choose the Live View/ Playback/ Device Manager/ File Manager/ Alarm Message/ General here. Details are as the following table:


Icons	Descriptions
 Live View	View live video
 Playback	Playback the recorded videos on SD card and hard disk remotely
 Device Manager	Add/Delete/Edit cameras and NVRs
 File Manager	Manage the image and video you operated in mobile device
 Alarm Message	Check alarm messages that pushed to your mobile device
 General	Make settings for the system

3.3 Device Manager

3.3.1 Add Device


1. Manual Adding

(1) Add Camera


Step 1: On the Device Manager interface, click  and select Add Camera.

Step 2: Click '▼' to select the register type including IP/Domain and P2P.

IP/Domain: Adding devices via IP or Domain.

P2P: It's suitable for internet environment, and you need to input the MAC address of the device (You can input the MAC address manually or click  to scan the bar code on the shell of the device or QR code on web page directly).

Milesight DDNS: Adding devices via Milesight DDNS


Step 3: Input the required information and click  to save device information.

① IP/Domain:

E.g.:

IP: 192.168.8.150

Port: 80




Name	IPC Device 1
Type	IP/Domain
IP	192.168.8.150
HTTP Port	80
User Name	admin
Password	

② P2P:


E.g.:

MAC: 1C:C3:16:20:00:EF



15:41

← Add Camera

Name	IPC Device 1
Type	P2P
MAC	1C:C3:16:20:00:EF 
User Name	admin
Password	


 **Note:**

- About P2P, you need to contact with Milesight to register your network camera first, otherwise it will be failed to connect.
- Before connecting P2P, please make sure that the camera is able to connect to the Internet.

③ Milesight DDNS:

E.g.:

Domain Name: ddns.milesight.com/2000EF



16:24

← Add Camera

Name	IPC Device 1
Type	Milesight DDNS
Domain Name	ddns.milesight.com/2000EF
User Name	admin
Password	Password

(2) Add NVR


Step 1: On the Device Manager interface, click , and select Add NVR.

Step 2: Click '▼' to select the register type including IP/Domain and P2P.

IP/Domain: Adding device via IP or Domain.

P2P: It's suitable for Internet environment, and you need to input the MAC address of device (You can input the MAC address manually or scan the QR code on web page or monitor directly).

Milesight DDNS: Adding devices via Milesight DDNS


Step 3: Input the required information and click  to save device information.

① IP/Domain

E.g.:

IP: 192.168.7.101

Port: 80




Name	NVR Device 1
Type	IP/Domain
IP	192.168.7.101
HTTP Port	80
User Name	admin
Password	

 **Note:** Default port is 80.

② P2P:


E.g.:

MAC: 1C:C3:16:0A:25:F6



15:40

← Add NVR

Name	NVR Device 1
Type	P2P
MAC	1C:C3:16:0A:25:F6 
User Name	admin
Password	


 **Note:**

- About P2P, you need to upgrade your NVR to latest firmware version and enable P2P on the NVR web or monitor, otherwise it will connect failed.
- Before connecting P2P, please make sure that the NVR is able to connect to the Internet.

③ Milesight DDNS:

E.g.:

Domain Name: ddns.milesight.com/2000EF




16:25

← Add NVR

Name	NVR Device 3
Type	Milesight DDNS
Domain Name	ddns.milesight.com/0A25F6
User Name	admin
Password	Password


3. Adding Device by Scanning QR code

It will be much convenient if you add device via P2P by scanning QR code.

Step 1: Click  and select Scan QR Code;

Step 2: Use your mobile device to scan the QR code which is on web page or monitor of device.


Step 3: It will skip to Add Camera or Add NVR interface automatically after you scanning QR code successfully, then input the user name and password and click save.



3.3.2 Edit Device

Step1: Click '✎', which is on the right of device, then it will jump to Edit Device interface.

Step2: Click the information you want to edit and click '💾', after editing. Or click '←' to quit.




Note:

- Click '✕' to clear selected column.

- You can't change the "Type" of the device.
- Click 'Play' to view live video of device directly.

3.3.3 Speed Test

Enter Edit Device interface, and then click 'Speed Test' to check delay time and uploading bandwidth of the NVR added by P2P.



 **Note:** For 'Speed Test' option, NVR's firmware version should be V7x.8.0.5 or above.

3.3.4 Delete Device

1. Delete Single Device


On the Device Manager interface, slide the device you want to delete to left, and it will pop up the button 'Delete'. Then click it to delete device. Or you can click any other place to cancel it.



2. Batch Deleting

Step 1: Click '☰↓' and select Batch Deletion or you can long press any device to enter Batch Deletion interface;

Step 2: Select devices you want to delete (you can click '☐☐' to select all device) and click '🗑️', the warning will pop up to ask you "Are you sure to delete", then click YES to delete selected devices.




3.4 Live View

3.4.1 Start Live View

Method 1: Click on Live View to enter the Device List interface, select device(s) which can be up to 64-CH for live view.


Method 2: Click on Live View to enter the Device List interface, select 1-CH for live view.



Refer to the following descriptions about icons on the Camera List interface.

Icons	Descriptions
	Main menu
	Back to Live View interface
	Network Camera/NVR
	Expand/Collapse list
	Select device(s) for live view

Click Play to back to Live View interface.




Refer to the following descriptions about icons on the Live View interface.



Icons	Descriptions
	Main menu
	Enter the Device List interface
	Add 1-CH for live view
	Quick Playback
	4 screen layouts
	Snapshot
	Record
	Start/Stop live view
	Speaker
	Microphone
	PTZ control panel
	Fisheye Client-side Dewarping
	Alarm Output
	Video stream control panel
	View Favorites
	Digital zoom


 **Note:**

- Double-click any window to enter full screen mode.
- In multi-screen mode, you can change the position of window by dragging and dropping it.
- The digital zoom function supports 16X amplification.

3.4.2 Stop Live View



Stop all live views: Click  to stop live view for all channels.

Stop single live view: Drag the window until '' shows up on the top of the screen. Drag the window to it until it changes to ''; then release the window.



3.4.3 Video Stream Control Panel

There are two video streams available including Primary and Secondary, and you can customize the parameters including frame size, frame rate, bit rate, I-frame interval and smart stream of video stream by clicking Custom.



Note: If the video is not smooth enough, please try to decrease bit rate and I-frame interval of camera.

3.4.4 PTZ Control Panel

Click to expand the PTZ control panel.



Refer to the following descriptions about icons on PTZ control panel.

Icons	Descriptions
	Start auto scan
	Control PTZ White LED (Only for iOS system)
	Zoom+/Zoom-
	Focus+/Focus-
	Iris+/Iris-
	Call preset
	Set preset
	Delete preset

Note:

- 99 presets(01~99) are supported.
- Slide up and down on the “0 0” to select preset point.












3.4.5 Fisheye Control Panel

Click to expand the fisheye control panel.



Refer to the following descriptions about icons about Installation mode and display mode on fisheye control panel. And the fisheye control can be operated by dragging on the screen.



Icons	Descriptions
	Click to select ceiling mounting



	Click to select wall mounting
	Click to select flat mounting
	Select live view of original fisheye view
	Select live view of 360° panoramic view
	Select live view of two 180° panoramic views
	Select live view of four regional views
	Select live view of one original view and three regional views
	Select live view of one 180° panoramic view and one regional view
	Select live view of one 180° panoramic view and four regional views
	Select live view of one 180° panoramic view and six regional views
	Select live view of one original fisheye view and eight regional views

 **Note:**

- The function is supported for the camera and NVR added by P2P or IP.

3.4.6 Alarm Output Control Panel


Click'  ', and the icon will light up as'  ', meanwhile the Alarm Output panel will pop up as shown below. Opening the switch will trigger on the corresponding Alarm Output, and it will maintain on for the duration time set on NVR.



 **Note:**

- Currently, only NVR supports this function.
- When the added device is camera, the Alarm Output capacity of this camera will determine the number of Alarm Output. For instance, for camera with two Alarm Outputs, the panel of Alarm Output will display one and two.
- When the added device is a NVR, the relevant Alarm Output of NVR will be first listed, that is, 1,2.etc, then camera Alarm Output, and the camera Alarm Output will display as CHx_x (such as CH1_1) according to the camera Channel and corresponding Alarm number


3.4.7 Quick Playback

Click '' to quickly skip to the playback interface, and it can automatically search for all types of video on that very day and plays automatically.







 **Note:** Currently, only NVR supports this function.

3.4.8 View Favorites


View Favorites is the function that you can save current screen layouts and all channels which are playing. Click '' to expand the View Favorites control panel.



Refer to the following descriptions about icons on View Favorites control panel.

Icons	Descriptions
	Add view
	Screen layouts of Favorites
	Play favorite view
	Edit view

Rename Favorites: Long press the Favorites and a window will pop up, input the new name of Favorites and click OK.





Delete Favorites: Slide the Favorites to the left, then 'Delete' will show up, click it to delete Favorites.




3.5 Playback

3.5.1 Start Playback

Method 1: Click  on Playback to enter Playback interface and select up to 4-CH for playback.

Method 2: Click  on Playback to enter Playback interface and select 1-CH for playback.




Refer to the following descriptions about icons on Device List interface.

Icons	Descriptions
-------	--------------

	Back to Playback interface
	Set the beginning and end time of recorded video

There are some settings you should make before starting playback.

- ① Set the start time and end time of the recorded videos.
- ② Select Stream Type of recorded video, it includes Primary and Secondary (Secondary by default).
- ③ Click '' to choose the Video Type including All, General and Event.
- ④ Select devices you want to playback.
- ⑤ Click Search to search video.



Refer to the following descriptions about icons on Playback interface.

Icons	Descriptions
	Main menu
	Enter the Device List interface
	Quick Preview
	Split Playback
	Start/Pause playback
	Transcoding
	Start/Stop playback
	Snapshot
	Record
	Adjust the play speed

	Fisheye Client-side Dewarping
	4 screen layouts
	Speaker
	Digital zoom


Note:

- All channels' playback are asynchronously, each channel has its own time bar.
- You can drag the time bar to adjust the playback time.
- Motion detection videos will be highlighted in the time bar, even if you only set up the continuous record
- Double-click any window to enter full screen mode.
- You can change the position of channel by dragging it.
- The time between the start time and end time can't be longer than one month.
- There are five options to adjust the play speed, including 1/4X, 1/2X, 1X, 2X, 4X.
- There are two ways to support the magnification of Playback time bar. You can click '' or

manually hold down '' to zoom the time bar.



3.5.2 Split Playback

Click '' to quickly skip to the Split Playback interface, and it can automatically search for all types of video on that very day and plays 4 split segments by fault.




You can click '', to set Start and End time of the Split Playback

video as shown below.




You can click to choose 4 or 9 split segments to play the recording video as shown below.



Note: Camera cannot support this function.

3.5.3 Transcoding

Transcoding aims to transcode the recorded stream into a smaller one, reducing the network load and providing better playback performance.




After successfully search out or play video, select the channel you want to transcoding and Click to expand Transcoding setting panel.



Then, set Transcoding, Frame Size, Bitrate and Frame Rate according to the network situation. The

worse network situation, the lower transcoding parameter should be.
At last, click Confirm to make transcoding take effect.






Transcoding		
Transcoding	On	Off
Frame Size	704*576	On
Bit Rate	128kbps	
Frame Rate	Auto	
Confirm		








3.5.4 Fisheye Control Panel

Click  to expand the fisheye control panel.




Refer to the following descriptions about icons about Installation mode and display mode on fisheye control panel. And the fisheye control can be operated by dragging on the screen.

Icons	Descriptions
	Click to select ceiling mounting
	Click to select wall mounting
	Click to select flat mounting
	Select live view of original fisheye view
	Select live view of 360° panoramic view

	Select live view of two 180° panoramic views
	Select live view of four regional views
	Select live view of one original view and three regional views
	Select live view of one 180° panoramic view and one regional view
	Select live view of one 180° panoramic view and four regional views
	Select live view of one 180° panoramic view and six regional views
	Select live view of one original fisheye view and eight regional views

3.5.5 Stop Playback

Method 1: Click  to stop playback of all channel. (Only for IOS system)


Method 2: Drag the window until  shows up on the top of the screen.

Drag the window to it until it changes to  then release the window.








3.6 File Manager


3.6.1 File Preview

Click the picture or video to view the file in full screen.



Refer to the following descriptions about icons on full screen.


Icons	Descriptions
	Exit full screen
	Delete picture or video
	Play video
	Play/Pause
	Capture a screenshot while playing (Only for Android)
	Decrease play speed
	Increase play speed

On preview mode, click  to open more files, slide the thumbnail line to view more. **(Only for Android.)**







3.6.2 Batch Management of the Files


Click  to enter Batch Management interface.



Batch Deleting: Select the file you want to delete or click  to select all. Click  to delete.

Batch Export: Select the file you want to export or click  to select all, and click  to export the selected file to any application you need;

Batch Saving: Select the file or click  to select all, and click  to save the selected files to local device (Only for iOS).






 **Note:**

- Video can only be exported to email.
- For Android, you can find all snapshots and videos in your mobile gallery, so you don't have to save them into mobile again.


3.7 Alarm Message


In order to check alarm messages on time, you can set device to push the alarm message to your mobile device and you can check alarm messages which received by your mobile device.




Open Alarm Push: Click  to enter Alarm Push interface, and click  to open alarm push for the device you want to get the alarm messages.



Check Alarm Messages: On Alarm Message interface, click  to select devices, then the alarm messages that it pushed will be shown as below.




Alarm Video Push: Click the alarm messages shown on Alarm Message interface of APP or Message Notification interface of mobile device to play the record files directly.




 **Note:**

Support Alarm Video Push of camera and NVR.

- 1) Make sure that camera's firmware version should be V4x.7.0.75 or above.
 - 2) Make sure that you have made correct settings on the NVR and mobile device so that you can get the alarm video or message on the mobile device.
- Make sure that you have made correct alarm settings and record schedule on the NVR.
 - Step1. Enable Alarm and do alarm settings. Don't forget to edit alarm effective time.




Step2. Set record schedule on Storage->Record Schedule(Only for Alarm Video Push).



- Make sure you have make relevant configuration about alarm video push.You can find the option in System->Network->More.


Step1. Enable Push Message and choose Push Stream Type.



Step2. Make configuration for Push Message Setting.

There are different Push Event Types for every channel to choose, which means every camera added in this NVR can choose what Event Type it wants to push, like Motion


Detection, Video Loss, Region Entrance, Region Exiting, Advanced Motion Detection, Tamper Detection, Line Crossing, Loitering and Human Detection.




- Make sure that you have enabled the information push for the APP on the mobile device (Only for iOS).
- Make sure that you have enabled the Alarm Push for devices on APP.
- Make sure that you have enabled the Alarm Video Push on General interface if you want to play record files by clicking the alarm messages.

3.8 General

On General interface, you can make some settings for M-Sight Pro.



iOS



Android


3.8.1 New Message Inform

This setting is only for iOS system. It shows the current status(Opened/Closed) that new message about the APP whether allows to be informed to your mobile device.


If the status is Closed, please set it in “Settings”->”Notifications” on mobile device.

3.8.2 Password Protection


Click Password Protection to enter Password Protection interface.




Turn On Password Protection: Select Turn On Password Protection. Then set the password and confirm.



Change Password: If you want to change the password, select Change Password. Input the old password and the new password to finish changing password.



Turn Off Password Protection: Once you turned on password protection, then the password needs to be input it every time you log in M-Sight Pro. If you want to turn off, select Turn Off Password Protection. Then input the password to turn it off.




3.8.3 Video Performance

Click Video Performance to select different options including Least Delay, Balanced and Best which will take different effects of video displaying, and Least Delay for default.

Least Delay: Real-time video for live view.

Best Fluency: The video has the best fluency.

Balanced: Between Least Delay and Best.




3.8.4 Remember Last Play

This option is for the live view, it decides whether continue last play when you start the APP.

Never: Never continue last play.


Always: Always continue last play.

Ask: Ask whether continue last play every time you start the APP.



3.8.5 Alarm Push Interval

Click Alarm Push Interval to set the interval which decides how long you can get the alarm message. The default alarm push interval is "Every 30 Seconds".




3.8.6 Image Ratio

This option determines the image ratio of camera on live view.

Resize: Images on the live view show with resize ratio, which could fit the size of the window.

Original: Images on the live view show with original ratio.




3.8.7 Alarm Video Push

Click the alarm messages shown on Alarm Message interface of APP or Message Notification interface of mobile device to play the recorded files directly.


 **Note:**

Support Alarm Video Push of camera and NVR.


- 1) Make sure that camera's firmware version should be V4x.7.0.75 or above.
 - 2) Make sure that you have made correct settings on the NVR and mobile device so that you can get the alarm message on the mobile device.
- Make sure that you have made correct alarm settings and record schedule on the NVR.
 - Step1. Enable Alarm and do alarm settings. Don't forget to edit alarm effective time.



Step2. Set record schedule on Storage->Record Schedule(Only for Alarm Video Push).




- Make sure you have make relevant configuration about alarm video push.
 - Step1.Enable Push Message and choose push stream type



Step2. Make configuration for Push Message Setting

There are different Push Event Types for every channel to choose, which means every camera added in this NVR can choose what Event Type it wants to push, like Motion Detection, Video Loss, Region Entrance, Region Exiting, Advanced Motion Detection, Tamper Detection, Line Crossing, Loitering and Human Detection.



- Make sure that you have enabled the information push for the APP on the mobile device (Only for iOS).
- Make sure that you have enabled the Alarm Push for devices on APP.
- Make sure that you have enabled the Alarm Video Push on General interface if you want to play record files by clicking the alarm messages.

3.8.8 Mobile Network Reminder

It will remind you when the APP detects you are using mobile network.

3.8.9 Show Stream Information


You can view real-time video stream information on the Live View interface if you enable it.

3.8.10 Bandwidth Saving Mode

If you enable this option, other channels will disconnect when one channel is full screen. And other channels will connect again when it turns back to former layout, which greatly saves bandwidth.

3.8.11 Help

You can get the introduction about the M-Sight Pro application.




Note:


- Click '↑' to back to the top of the article.
- Click the text in Main Feature to skip to the corresponding introduction part.

3.8.12 About

You can get the version, new features, privacy policy (only for ios), check online update about the APP and contact us.



iOS



Android

3.9 About device

Camera added via P2P doesn't support Microphone.

NVR added via P2P doesn't support Microphone.

NVR added via IP doesn't support Microphone.

Chapter IV Service

Milesight Technology Co., Ltd provides customers with timely and comprehensive technical support services. End-users can contact your local dealer to obtain technical support. Distributors and resellers can contact directly with Milesight for technical support.

Technical Support Mailbox: support@milesight.com

Web: <http://www.milesight.com>

Online Problem Submission System: <http://www.milesight.com/service/feedback.asp>

MILESIGHT USA

TEL: +1-800-561-0485

Mail: sales@milesightusa.com

Add: 7509 N.W. 36th Street, Miami, Florida 33166, USA

MILESIGHT KOREA

TEL: +82-2-839-3335

Mail: charley@milesight.co.kr

Add: 9F/925, 25-32, Anyang SK V1 Center, LS-ro 116beon-gil, Dongan-gu, Anyang-si, Gyeonggi-do, Korea

MILESIGHT CHINA

TEL: +86-592-5922772

Mail: support@milesight.com

Add: No.23 Wanghai Road,2nd Software Park, Xiamen, China

Milesight
Better Inside, More in Sight